

ALCOHOL BREATH ANALYSER AA - 3510



- Our Digital Alcohol Breath Analyser is designed with advanced technology and user friendly approach. Salient features of our digital breath alcohol analyser are: Large display and inbuilt printer.

- **SPECIFICATIONS :**

Sensor	Fuel Cell: Fuel cell gas sensors are based on the oxidation of ethanol to acetaldehyde on an electrode. The current produced is proportional to the amount of alcohol present.
Printer	In-built printer or can be detached from alcohol analyser, wireless printer
Display	Color 3.2" TFT LCD with touch screen
Navigating	Navigating key input with Touch Panel
Memory	Upto 50,000 readings
Digital Output	Through USB
Mouthpiece	Yes, and removable
Power supply	Li-Ion batteries, Rechargeable
Auto flow monitoring	Through inbuilt mechanism
Detection Range	0.000-0.400% BAC or 0,000-2.000 mg/L
Operating temperature	-20°C To +85°C
Humidity	95% Rh
Dimensions	171 X 92 X 32 mm

▶▶ **Regulatory compliances**



▶▶ **Corporate Social Responsibility**

Analytical Foundation is a Nonprofit Organization (NGO) found for the purpose of:



Analytical Foundation

1. Research & Innovation Scientist's awards / QC Professional Award: Quality life is possible by innovation only and the innovation is possible by research only, hence ANALYTICAL FOUNDATION is committed to identify such personalities for their contributions across various field of Science and Technology and awarding them yearly. To participate for award, send us your details of research / testing / publication at info@analyticalfoundation.org

2. Improving quality of life by offering YOGA Training courses, Work shops / Seminars etc.

3. ANALYTICAL FOUNDATION aims to DETOXYFY human minds, souls and body by means of Yoga, Meditation, Ayurveda, Health Care, Awards, Media, Events, Camps etc.

▶▶ **Reach us @**

