

# Electronic Methanometer



EPC / PRODUCTS / APPLICATION / SOFTWARE / ACCESSORIES / CONSUMABLES / SERVICES

**Analytical Technologies Limited**

An ISO 9001 Certified Company

[www.analyticalgroup.net](http://www.analyticalgroup.net)

Simultaneously monitor and display up to five atmospheric hazards with the GasAlertMicro 5.

Adaptable to a variety of applications, the GasAlertMicro 5 has an extensive selection of user-settable field options and is available as either a standard toxic gas model, a PID model for the detection VOCs, or an IR model for CO<sub>2</sub> detection.

Use the passcode function to prevent unauthorized modifications of the instrument's settings. Compatible with BW's MicroDock II automatic test and calibration system, the GasAlertMicro 5 is unparalleled in its versatility, performance and overall value.

### ►► **Protect Yourself**

- Compact (5.7 x 2.9 x 1.5 in. / 14.5 x 7.4 x 3.8 cm) and lightweight (13.1 oz. / 370 g).
- Rugged, highly water-resistant design.
- Continuous LCD shows simultaneous gas concentrations for five gases.
- Integral concussion-proof enclosure for the most rugged environments.
- Integral motorized pump option for remote sampling (optional).
- Two power options: three AA alkaline batteries or a rechargeable battery pack.
- Provides 95 dB alarm tone and two bright wide-angled alarm bars.

- Equipped with internal vibrating alarm for high noise areas.
- Three backlight options: standard-activates in low light (auto), in alarm (auto) and reactivates on-demand; alarm only-activates in alarm conditions and reactivates on-demand; stealth mode.
- Four alarm levels: instantaneous Low and High Alarm for all gases; TWA (time weighted average) and STEL (short term exposure limit) for toxic gases.
- Multi-language support in English, French, German, Spanish and Portuguese.
- Simple automatic calibration procedure; compatible with BW Micro Dock II system.
- Records TWA, STEL and maximum exposures to gas and displays readings on command.
- User selectable field options include: confidence beep, pass code protection, latching alarm, calibration due date and "SAFE" display function, stealth mode, selectable ppm resolution for some gases (e.g. SO<sub>2</sub> 0.1 ppm).
- Full function self-test of: sensor, battery and circuit integrity; and audible / visual alarms.

## Regulatory compliances



## Corporate Social Responsibility

Analytical Foundation is a nonprofit organization (NGO) found for the purpose of:



# Analytical Foundation

1. Research & Innovation Scientist's awards/QC Professional Award : Quality life is possible by innovation only and the innovation is possible by research only, hence ANALYTICAL FOUNDATION is committed to identify such personalities for their contributions across various field of Science and Technology and awarding them yearly. To participate for award, send us your details of research / testing / publication at [Info@analyticalfoundation.org](mailto:Info@analyticalfoundation.org)

2. Improving quality of life by offering YOGA Training courses, Work shops/Seminars etc.

3. ANALYTICAL FOUNDATION aims to DETOXYFY human minds,souls and body by means of yoga, Meditation, Ayurveda, Health Care, Awards, Media, Events, Camps etc.

## Reach us @



HPLC Solutions   MultipleLabs   Analytical Bio-Med   Analytical Distributors   Analytical Foundation (Trust)

**Corporate & Regd. Office:**  
Analytical House, # E67 & E68,  
Ravi Park, Vasna Road, Baroda,  
Gujarat 390 015. INDIA

T: +91 265 2253620  
+91 265 2252839  
+91 265 2252370  
F: +91 265 2254395

E: [info@hplctechnologies.com](mailto:info@hplctechnologies.com)  
[info@multiplelabs.com](mailto:info@multiplelabs.com)  
[info@analyticalgroup.net](mailto:info@analyticalgroup.net)  
[info@analyticalbiomed.com](mailto:info@analyticalbiomed.com)

W. [www.analycalgroup.net](http://www.analycalgroup.net)  
[www.hplctechnologies.com](http://www.hplctechnologies.com)  
[www.multiplelabs.com](http://www.multiplelabs.com)  
[www.ais-india.com](http://www.ais-india.com)

Sales & Support Offices:  
across the country :  
Distributors & Channel  
partners World Wide