





Sanitizing Equipments



PERSONNEL SANITIZING TUNNEL



PERSONNEL SANITIZING WALKWAY



SANITIZING CONVEYOR

EPCC / PRODUCTS / APPLICATION / SOFTWARE / ACCESSORIES / CONSUMABLES / SERVICES


Analytical Technologies Limited

An ISO 9001 Certified Company

www.analyticalgroup.net

►► PERSONNEL SANITIZING TUNNEL

ATL Sanitizing Tunnel is installed at the entry side of the main gate area to facilitate easy sanitizing of personnel & visitors at the time of entry. The sanitizing tunnel helps contain the Viruses and Contaminants that are over the clothes and external wear of the Personnel entering the Premises.




PERSONNEL SANITIZING TUNNEL

►► DOOR WAY GATE SANITIZING TUNNEL:

Walk Through Opening	1100mm(w) X 2200 mm(h)
Base grating for Personnel	1000mm (w) X 1600mm(l)
Base Collection tank	40 ltrs, drain outlet 1" Bsp
Power supply	440v 3PH 50 Hz
Sanitizing Pump	0.5 hp, 10 Lpm
Dosing Pump	6 Lph, PP
Sanitizing Nozzles	Misting type
Sanitizing Solution Tank	40 Ltrs
Tunnel MOC	SS 304/M.S/PPGI (As per customers requirement)
Air Blow Tunnel	(optional)
Control Panel	With automatic control, timer, emergency stop

►► PERSONNEL SANITIZING WALKWAY

ATL Sanitizing Walkway is installed at the entry side of the main gate area to facilitate easy sanitizing of personnel at the time of entry to work places. The walk through the sanitizing walkway helps contain the Viruses and Contaminants that are over the clothes and external wear of the Personnel entering the Premises.



PERSONNEL SANITIZING WALKWAY

►► MEDIUM SIZE SANITIZING TUNNEL:

Automatic operation	Yes
Power (HP)	1hp
Nozzle	9 Misting Nozzles
Sensor for Person Entry	Yes
Chemical Dosing Pump	Yes
Walk Through Opening	1100mm(W) X 2200 mm(H) X 1600(L)
Base Collection tank	40 ltrs, drain outlet 1" Bsp
Dosing Pump	6 Lph, PP.
Sanitising Pump	0.5 hp, 20 Lpm.
Drainage System	Base Tank Provided with drain connection
Construction	SS 304/M.S/PPGI (As per customers requirement)
Sanitizing Trolley	With Dosing pump ,sanitizer tank and Auto Panel
Inlet Outlet Curtains	PVC Curtains Provided at Inlet and Outlet

►► LONG SANITIZING WALKWAY TUNNEL:

Automatic operation	Yes
Power (HP)	1hp
Nozzle	27 Misting Nozzles
Chemical Dosing	Yes
Walk Through Opening	1100mm(W) X 2200 mm(H) X 2400(L)
Sanitizing Solution tank	100 ltrs
Dosing Pump	6 Lph, PP.
Sanitizing Pump	0.5 hp, 30 Lpm.
Construction in Tubular structure and PPGI sheeting, SS 304 canopy available as well	
Sanitizing Trolley	With Dosing pump ,sanitizer tank and Auto Panel
Inlet Outlet Curtains	PVC Curtains Provided at Inlet and Outlet

FEATURE DESCRIPTION	SANITIZING WALKWAY AUTOMATIC	SANITIZING TUNNEL WALKWAY SEMI AUTOMATIC
Mist Overspray collection	Provided with SS 304 Enclosure/MS (as per customer requirements)	Provided with PPGI enclosure & M.S and SS also available (as per customers requirement)
Mist Overspray collection	Yes in base collection tank	No base tank,
Sanitizer Tank capacity	40 Ltrs SS 304	100 ltrs , PVC
Auto refilling of Sanitizer through dosing Pump	Yes Provided	Yes Provided
Automatic sensing of person entry and mist start and Stop	Yes Provided	Not Provided, shall be managed by operator
Automatic refilling of water in sanitizer tank after reaching refill level	Yes Provided	Yes Provided
Civil Work Required at Site	Not Required	Floor sloping will be required at site, leading to drain
Drain connection required	Yes	Floor sloping will be required at site, leading to drain
Water Inlet Connection Required at Site	Yes	Yes
No Of Persons who can get Sanitized per minute	4	10
Site Assembly work Required	Not Required	Required
Ideally can be Used in	Hotels/ Buildings/ Offices	Factories/ malls/ Stations/ Bus Stands/ Schools
Space Required	8ft X 10 Ft	12 Ft X 10 Ft
Shipping Condition	Packed, assembled	Semi Knocked Down Condition, to be assembled

►► SEMI AUTOMATIC

- Manual Tank mixture refilling
- Plastic Tanks
- No drainage and collection tank
- Civil Structure needed

►► FULLY AUTOMATIC

- Separate SS 304 Sanitizing Solvent and Water Tank and Sensor Based Dispensing System
- Motion Sensor
- Drain Tank with out let connection
- Auto Start
- Canopy option SS/MS/FLEX

►► HOW AUTOMATIC SANITIZING EQUIPMENT WORK

In these equipment's the Sanitizing is done in an enclosure, by mist spraying the sanitizing solution through especially designed mist spray nozzles working on the principle of atomization of solution into very fine mist using high pressure pump. The Sanitizer solution tank is provided with a dosing pump which will dose the required quantity of sanitizer solution each time the tank is filled with fresh water. The system operates automatically as a person enters the Tunnel and the spray starts, it stops after a pre-set time of spraying after a person has entered the Tunnel.

►► SANITIZING EQUIPMENT MODELS


SIZE L X B X H	SS 304	MS FLEX	FLEX CANOPY
4.4ft X 7ft	✓	✓	✓
5.25ft X 4ft X 7ft	✓	✓	✓
7.8ft X 4ft X 7ft	✓	✓	✓
Automation	Fully Automatic	Semi Automatic	Semi Automatic

►► SANITIZING CONVEYOR

ATL Sanitizing Conveyor Tunnel is designed to reduce workplace risk of contaminants and enhance safety. Every day, packaged ingredients stored in containers, buckets, packed meats, and bags are brought into plants on delivery trucks, and could have been exposed to contaminants or viruses.

►► SANITIZING CONVEYOR:

Envelope Size	500mm(w) X 400 mm(h)
Conveyor speed	1-3 mtrs/ min (variable)
Conveyor Drive	Frequency Inverter Controlled
Power supply	440v 3PH 50 Hz
Sanitizing Pump	0.5 hp, 10 Lpm
Dosing Pump	6 Lph, PP
Tunnel MOC	SS 304
Filter	SS wiremesh type
Sanitizing Nozzles	Misting type
Sanitizing Solution Tank	40 Ltrs
Control Panel	With automatic control, timer, emergency stop



HPLC Servicing, Validation, Trainings and Preventive Maintenance :

HPLC Servicing :HPLC Servicing : We have team of service engineers who can attend to any make of HPLC promptly @the most affordable cost.

Trainings :We also take up preventive Maintenance to reduce downtime of HPLC's Trainings.

AMC's/CMC :AMC's/CMC :We offer user training both in-House and at customer sites on HPLC principles, operations, trouble-shooting.

Validations :Validations :We have protocols for carrying out periodic Validations as per GLP/GMP/USFDA norms.

Instruments :Instruments :We offer instruments/Renting Services Modules like pumps,detector etc. on Rent.



About Analytical Technologies

Analytical Technologies is synonymous for offering technologies for doing analysis and is the Fastest Growing Global Brand having presence in at least 96 countries across the global. Analytical Technologies Limited is an ISO:9001 Certified Company engaged in Designing, Manufacturing, Marketing & providing Services for the Analytical, Chromatography, Spectroscopy, Bio Technology, Bio Medical, Clinical Diagnostics, Material Science & General Laboratory Instrumentation. Analytical Technologies, India has across the Country operations with at least 4 Regional Offices, 6 Branch Offices & Service Centers. Distributors & Channel partners worldwide.

Our Products & Technologies



UV/VIS
Spectro 2080+
Double Beam



Infra FTIR



Optima Gas
Chromatograph
3007



Optima Gas
Chromatograph
2979 Plus



Flash
Chromatograph



Atomic Absorption
Spectrophotometer



Liquid Particle
Counter



Optical Emission
Spectrophotometer



DSC/TGA



Semi Auto Bio
Chemistry Analyzer



HEMA 2062
Hematology
Analyzer



Micro Plate
Reader/Washer



URINOVA 2800
Urine Analyzer



Total Organic
Carbon 3800



Fully Automated
CLIA



NOVA-2100
Chemistry Analyzer



PCR/Gradient PCR/
RTPCR



TOC
Analyzer



Laser Particle
Size Analyzer



Ion Chromatograph



Water purification
system

Regulatory compliances



Corporate Social Responsibility

Analytical Foundation is a nonprofit organization (NGO) found for the purpose of:



Analytical
Foundation

1. Research & Innovation Scientist's awards/QC Professional Award : Quality life is possible by innovation only and the innovation is possible by research only, hence ANALYTICAL FOUNDATION is committed to identify such personalities for their contributions across various field of Science and Technology and awarding them yearly. To participate for award, send us your details of research / testing / publication at Info@analyticalfoundation.org

2. Improving quality of life by offering YOGA Training courses, Work shops/Seminars etc.

3. ANALYTICAL FOUNDATION aims to DETOXYFY human minds,souls and body by means of yoga, Meditation, Ayurveda, Health Care, Awards, Media, Events, Camps etc.

Reach us @

